

## FOOTNOTES

- AA** Requires temporary removal of bumper during installation.
- AB** Requires four (4) 3/8" spacer blocks (Kit #01077) for installation. (Sold separately)
- AC** Hitch rated at 1,000 lbs. GTW, 100 lbs. TW.
- AD** Hitch rated at 1,500 lbs. GTW, 150 lbs. TW.
- AE** Hitch rated at 2,500 lbs. GTW, 200 lbs. TW.
- AG** Drawbar Kit (28451) & Accessory Adapter (28351) sold separately.
- AH** Requires temporary removal of muffler during installation.
- AI** Additional installation time required.
- AL** Additional installation time required for vehicles equipped with load leveling compressor.
- AM** Not recommended on Trofeo models prior to 1989. 1989 units require minor fascia trim and exhaust repositioning.
- AO** Will not fit vehicles with twin tailpipes.
- AW** Will not fit Turbo models.
- AY** Does fit SE models with Sport Appearance Package, GT model or 4 Dr. STE.
- BF** Requires standard bumper. Will not fit with step bumper.
- BK** For vehicles without bumper, #02879 must be used (Sold separately).
- CA** Models with dual exhaust require exhaust modification.
- CC** Requires minimum of 19" from end of frame rail to spring shackle bracket.
- CH** T-One is equipped with circuit protected ModuLite™ module.
- CM** OEM Style Attachments/Requires Factory Bumper For Hitch Installation.
- CN** Requires OEM factory bumper for hitch installation.
- CO** Will not fit 8 ft. 2500/3500 Series with heavy-duty suspension or four door Crew Cab.
- CP** Fits All Models without Factory Installed Receiver.
- CQ** Will not fit with heavy duty suspension.
- CR** Fits with mini spare tire stowed under vehicle. Will not fit with full size spare.
- CS** Will fit with full-size spare tire stowed under vehicle.
- CU** Includes models with large fuel tank and skid shield.
- DA** Will not fit with tube style bumper.
- DB** Will not fit 6 ft. bed pickups.
- DG** 1971-77 (Standard) Van: Will not fit with optional large gas tank. 1974-77 (Maxi) Van: Includes models with optional large gas tank.
- DH** Cannot be installed on 1987-97 vehicles with factory step bumpers unless step bumper and its mounting brackets are permanently removed and standard factory bumper is installed.
- DU** Fascia removal required.

- DX** Requires six 3/8" spacer blocks (#01077-011) and six 1/2-13 x 2-1/4 GR5 carriage bolts (#01266-009) which are not provided (Sold separately).
- DY** Use On 1500 Models Built After 11/1/02.
- EB** Factory electrical bracket will NOT fit with this hitch. Must use aftermarket electrical box or bracket.
- EF** Fits all models with standard bumpers.
- EG** Relocation of spare tire bracket is not required. NOTE: 19mm open end style wrench must be purchased to allow removal of spare tire after hitch installation.
- EK** Extended Cab only.
- EO** Requires longer ball mount.
- EP** Fascia trimming required.
- FB** Will not fit vehicles fitted with optional 31" tires stowed under vehicle.
- FE** Fascia trimming required. Allow additional installation time.
- FM** On vehicles equipped with load leveling device, air pump mounting modification required.
- FP** Spare tire repositioning and/or modification of spare tire carrier may be required.
- FS** Includes 2 & 4 WD models with heavy duty suspension.
- FV** 2003 Models w/Build date after 11/1/02.
- FW** 2003 Models w/Build date before 11/1/02.
- FX** Fits vehicles with spacer between E/A unit and frame built before Jan.'93 and after Mar.'93.
- GC** T-One is equipped with ModuLite Lite™ module.
- GE** Will not fit vehicles with dealer installed ground effects.
- GH** Will not fit models with 34" wide frames.
- GP** Hitch crosstube concealed behind bumper.
- GU** Will not fit vehicles with factory or aftermarket lower Fascia/Rollpan or Tube Bumper.
- GW** Spare tire cannot be stowed under vehicle on short wheelbase models equipped with 15" tires or full size spare.
- GX** Requires fabrication of "L" bracket to reposition exhaust on '95 and later 6 ft. box models.
- HA** External dress panel beneath 95-97 and 03-05 vehicles must be removed for hitch installation.
- HB** Slight fascia deformation may occur on some models.
- HC** Will not fit with mini or full size tire stowed under vehicle.
- HD** Will not fit 6 ft. bed pickups except 6 ft. Super Cab.
- HJ** Per Dodge owner's manual: If trailer is with more than standard lighting (1 tail light per side), use of ModuLite™ or dealer supplied harness is required.
- HK** Under vehicle spare tire stowage may be retained with installation of an aftermarket spare tire repositioner. Cutting of rollpan in license plate area required for receiver tube access. Does not fit with bumper.
- HM** Hitch crosstube is visible beneath bumper.
- HX** Minor exhaust modification may be required.

- HY** Ultra Frame ball mount #4283 cannot be used in rise position on vehicles with step bumpers.
- J** Under vehicle spare tire stowage is retained.
- JF** Will not fit with 16" spare tire.
- JL** Installation requires OEM bumper and brackets.
- JM** 1994 models built thru 2/94 require T-One # 118348.
- JR** Exhaust must be temporarily lowered for installation.
- JT** 2WD models only.
- JU** License plate relocation required to install hitch, see 5443. (Sold separately)
- JV** Rubber air deflector/fascia must be removed or trimmed to install hitch.
- JW** 4WD models only.
- JX** Requires factory tow hooks for installation on 2WD models.
- JY** Extensive fascia cutting required on models w/fog lamp option.
- JZ** Requires factory stabilizer (anti-roll) bar for hitch installation.
- K** Adapter kit (#1685) required with #41504 for 1980 and later F-Series pickups.
- KB** Diesel engine models only.
- KC** Does not fit 2500/3500 2WD (C-Series) models w/8 lug wheels.
- KD** Fits 2500/3500 2WD (C-Series) models w/8 lug wheels only.
- KE** Does not fit 88-91 4 Dr. Crew Cab models.
- KF** Will not fit Flareside.
- KG** Skid shield must be removed if present.
- KH** Minor heat shield modification may be required.
- KI** Optional OEM Fog Lights must be removed for receiver installation.
- KK** When installing on a vehicle originally equipped with an OEM hitch, OEM bumper brackets must be purchased and installed prior to new hitch installation.
- KL** Hitch is designed to attach beneath the OEM hitch.
- L** Exhaust repositioning required.
- LS** T-One incorporates low-side switching tail light converter. Additional installation time required.
- LT** Requires removal of factory hitch if equipped.
- M** Will fit with heavy-duty suspension.
- MB** Will not fit models equipped with air suspension package.
- O** Will not fit vehicles equipped with dual exhaust exiting below the bumper.
- PA** Will not fit 124" wheelbase or E350 models.
- PW** For 124" wheelbase and E350 models, adapter kit (2626) is required. (Sold separately)
- RA** Do not install on early 1996 models equipped with M10 fasteners.
- RB** Hitch installation can be made easier with a "cutter" type drill bit.

- RD** For vehicles equipped with factory tow packages, may require additional components or may be used as a replacement harness.
- RJ** Short box models with 31/10.5/R15 spare tire will NOT retain under vehicle spare tire storage.
- RO** Will not fit Silverado SS.
- SA** Requires drilling on 6 ft. bed models.
- SC** Minor trimming of plastic trunk pan required.
- SE** Will not fit models with short wheelbase and rear stabilizer (anti-roll) bar.
- SO** With this hitch installed, the step bumper is no longer able to be used as a towing point.
- SR** Only use ball mounts with 8-1/2" length, 3/4" rise and 2" drop for this vehicle.
- SV** Trimming or removal of underbody appearance panel required.
- SY** Hitch crosstube is visible beneath bumper with a more than normal gap between fascia and crosstube.
- T** Vans with step bumpers require longer ball mounts.
- TA** Trunk access required for hitch installation.
- TD** Hitches without electrical bracket rated at 350/3500 WC & No WD. Hitch with electrical bracket rated at 400/4000 WC & No WD.
- TE** Will not fit vehicles equipped with 19" full size spare tire.
- TF** For 3/4 and 1 ton vehicles only.
- V** For vehicles with factory installed step bumpers only.
- VB** Will not fit vehicles with vibration damper installed at rear of frame on drivers side.
- VR** Hitch has a vertical receiver tube. Not compatible with most bike racks.
- X** Minor fascia trimming required.
- YA** Will not fit 15 passenger models.
- YB** 1500 series only
- YC** 2500 series only
- YE** Vehicle must be equipped with a factory tow package.
- YF** Will not fit Daytona, Hemi Sport Quad Cab, Rumble Bee or SRT-10 models.
- Z** May be equipped with Factory Tow Prep Plug. Determine at time of installation.