

**Note:** Some models come equipped with an appearance panel that covers the trunk pan. This will need to be removed and returned to the owner, or trimmed to fit and reinstalled (see figure 1-1 above).

- 1. Lower the exhaust by detaching it from the rubber isolator, support the exhaust to prevent damage to the vehicle.
- 2. Raise the hitch into position and install (6) hex bolts and conical washers into existing weld nuts in the frame rails (3) per side. Torque all fasteners to 68 LB-FT
- 3. Raise the exhaust back into position and reattach the rubber isolator.

## Thank you for purchasing a Rigid Hitch

Hardware Package:

(6) M12 x 1.25 x 40mm Hex Bolts (6) 1/2" Conical Washers

## GIVE THIS INSTRUCTION SHEET TO VEHICLE OWNER



THIS PRODUCT COMPLIES WITH SAFETY SPECIFICATIONS AND REQUIREMENTS FOR SAE AND VESC REGULATION V-5 FOR CONNECTING DEVICES AND TOWING SYSTEMS. <u>DO NOT MODIFY</u> <u>THIS PRODUCT.</u> INSTALL ONLY ON SPECIFIED VEHICLES IN GOOD CONDITION.

