

# INSTALLATION MANUAL

# 13602

## Level of Difficulty

Moderate

Installation difficulty levels are based on time and effort involved and may vary depending on the installer level of expertise, condition of the vehicle and proper tools and equipment.

## Weight Carrying Capacity

Gross trailer weight (GTW)	5,000 lbs.
Tongue weight (TW)	500 lbs.

## Weight Distribution Capacity

Weight distribution (WD)	5,000 lbs.
WD tongue weight (WDTW)	500 lbs.

## Parts List

Item	Qty	Description
1	1	Trailer hitch
2	4	Hex bolt, M14 1.5, 60
3	4	Conical-toothed washer, 9/16"
4	1	Hex bolt, M14 1.5, 30

## Tools Required

Ratchet	Torque wrench
Socket, 10mm	Torque adapter, 22m
Socket, 14m	Rotary tool
Socket, 22m	Cut-off wheel

\* For a tools reference guide visit [curtmfg.com/trailer-hitch-installation](http://curtmfg.com/trailer-hitch-installation)

## ⚠ WARNING

Never exceed the vehicle manufacturer's recommended towing capacity.

## Product Photo



## NOTICE

Visit [www.curtmfg.com](http://www.curtmfg.com) for a full-color copy of this instruction manual, as well as helpful videos, guides and much more!

Before you begin installation, read all instructions thoroughly.

Proper tools will improve the quality of installation and reduce the time required.

This installation requires:

- Underbody panel trimming

Periodic inspection of the trailer hitch should be performed to ensure all mounting hardware remains tight and structural components are secure.

To help prevent damage to the product or vehicle, refer to the specified torque specifications when securing hardware during the installation process.

## SAFETY INSTRUCTIONS

Safety glasses should be worn at all times while installing this product.




## Product Registration and Warranty

CURT stands behind our products with industry-leading warranties. To get copies of the product warranties, register your purchase or provide feedback, visit: [warranty.curtgroup.com/surveys](http://warranty.curtgroup.com/surveys)

# ASSEMBLY

## Parts List


Item	Qty	Description
1	1	Trailer hitch
2	4	Hex bolt, M14 1.5, 60
3	4	Conical-toothed washer, 9/16"
4	1	Hex bolt, M14 1.5, 30



### Step 1

Remove the rear-most underbody panel by removing eight push fasteners and three nuts with a 10mm socket, and one nut with 14mm socket.

Trim underbody panel using the rectangle guide in the panel as shown.



### Step 2

Install a tube spacer on the driver-side frame rail by bolting the middle hole of the spacer using an M14 hex bolt (#4) to the middle hole of the frame rail with the larger hole facing outwards.


**Note:** Temporarily installing a bolt into one of the remaining holes will help prevent the spacer from rotating when tightening.



### Step 3

Raise the hitch, hooking the driver side over the lip of the frame rail and rotate the hitch into position.

Loosely secure with remaining M14 bolts (#2) and conical-toothed washers (#3).



### Step 4

Torque all M14 bolts to 95.1 ft-lbs. If a torque adapter is used, adjust the torque accordingly.

Reinstall the underbody panel.



## TOWING BASICS & SAFETY INFORMATION

For information on safely towing your trailer, visit [curtmfg.com/understanding-towing](http://curtmfg.com/understanding-towing).